

# Fast and easy for perfect sensor settings.


## 9 scenarios for True Presence®

Modern-day presence detectors frequently interpret vibrations or electrical interference as movement, resulting in inadvertent triggering. Our engineers have addressed this problem. For this, the resolution sensitivity of STEINEL True Presence® sensors can be adjusted digitally. In the app you will find 9 preset scenarios with sensor specifications matched to the particular application.



steinel

## Standard scenarios



### Small office...

...quiet workstation

#### Scenario 8

This scenario provides standard sensitivity for office workstations.

## Variations

...with silent work

#### Scenario 9

As scenario 8, but with a higher sensitivity.



### Large office...

...quiet workstation

#### Scenario 8

This scenario provides standard sensitivity for office workstations.

...busy entrance area

#### Scenario 7

As scenario 8, but with a further reduced sensitivity.



### Hotel room

...with person asleep

#### Scenario 6

This scenario also provides maximum sensitivity. In addition, signal processing has been optimised to reliably detect the presence of persons sleeping.

...with sources of interference (e.g. air-conditioning system)

#### Scenario 5

As scenario 6, with slightly reduced sensitivity.



### Industry

... workplace without silent work (assembly line, warehouse)

#### Scenario 4

This scenario provides high sensitivity. To prevent undesired switching, it should be used for smaller areas.

...lots of movement or large machines

#### Scenario 3

As scenario 4, with slightly reduced sensitivity.



### Heavy industry...

...large machines, fork-lift trucks

#### Scenario 2

This scenario should be used if there are larger vibrations or if there are sources of electrical interference. The True Presence function is not available, the sensor functions as a conventional motion detector.

...very strong vibrations

#### Scenario 1

As scenario 2, with a slightly reduced sensitivity.

# Detailed settings.

In the overview below you can see the basic settings of the 9 scenarios. Based on these, you can make individual adjustments to meet your requirements.

Scenario	Title	Presence detection	Breath detection (True Presence®)	Detection of sleeping people	Sensitivity	
					for movement	True Presence®
1	Room with strong vibrations (e.g. industry)	●			■■■ ■■■ ■■■	■■■ ■■■ ■■■
2	Room with low vibrations (e.g. industry)	●			■■■ ■■■ ■■■	■■■ ■■■ ■■■
3	Common corridors and halls	●	●		■■■ ■■■ ■■■	■■■ ■■■ ■■■
4	Large corridors and halls	●	●		■■■ ■■■ ■■■	■■■ ■■■ ■■■
5	Common hotel, bedroom and living rooms	●	●	●	■■■ ■■■ ■■■	■■■ ■■■ ■■■
6	Large hotel, bedroom and living rooms	●	●	●	■■■ ■■■ ■■■	■■■ ■■■ ■■■
7	Large office with lots of movement	●	●		■■■ ■■■ ■■■	■■■ ■■■ ■■■
8	Standard office	●	●		■■■ ■■■ ■■■	■■■ ■■■ ■■■
9	Small office with silent work	●	●		■■■ ■■■ ■■■	■■■ ■■■ ■■■



For more information  
scan the QR code

steinel